
Security check and advice for use - Please read this before you start!

- Check the brakes, chain, tyres and general state of the cycle.
- Passengers should wear approved cycle helmets.
- When children climb in and out, the cycle will tip down in front unless held from the back of the cycle.
- Make sure that passengers are seated and wearing their safety belts correctly.
- When riding with only one child, he/she should be placed in the centre, to distribute the weight evenly.
- The cycle's maximum load capacity is 100 kg, excl. driver.
- Ride carefully and with consideration. Avoid dangerous situations.
- Be aware of the width of the cycle, and be considerate of others in the traffic
- Adapt the speed to the road conditions. Take care when taking sharp bends and corners.
- When it runs without a load, the cycle may tip more easily when taking sharp bends and corners.
- When the load is heavy, the braking length of the cycle is longer.
- When the Kangaroo is used after sunset, it must be fitted with two front lights and a rear light.
- The front flap protects the passengers from insects and thrown-up pebbles, so it should always be fitted when riding.

